



ALARM.COM®

Alarm.com Wireless Video Doorbell

ADC-VDB780B
DATA SHEET

Key features

- Completely wireless installation
- Rechargeable (micro USB) battery pack
- Optimized for battery life that is expected to last up to six months
- Advanced motion detection provides increased awareness with timely alerts
- Two-Way Audio through the mobile app
- Installation flexibility for optimal viewing
- 160° horizontal FOV
- Full HD 1080p recording
- Wi-Fi connection to the Alarm.com Smart Chime (ADC-W115C) or Smart Gateway (ADC-SG130) (sold separately) required



Overview

The Alarm.com Wireless Video Doorbell is a battery-powered doorbell camera that features HD video, Video Analytics for rapid people detection, Two-Way Audio, a wide field of view, and a rechargeable battery.

This completely wireless video doorbell gives you the flexibility to choose the perfect installation location without depending on the existing wiring or chime. The VDB780B must be connected over Wi-Fi to the Alarm.com Smart Chime (ADC-W115C).

Specifications

Recording compression: H.264

Ingress protection: IP66

Max resolution: 1920x1080

Image sensor:

2.12 MP - 1080p, Sony IMX323 ABR control support and MJPEG

Lens/angle of view:

160° horizontal, 90° vertical, 175° diagonal

Low-light sensitivity:

0.5 lux with IR LED off IR range: Up to 15 feet (5 meters)

Image adjustments:

Flip, brightness, contrast, saturation, sharpness, exposure

Wi-Fi connectivity: 802.11 b/g/n, 2.4 GHz

Operating and storage temperatures:

-4°F to 122°F (-20°C to 50°C)

Operating humidity:

20% to 100% (non-condensing)

Dimensions:

(W x L x D) 2.5 x 5.3 x 1.2" (64 x 134 x 30 mm); mounting bracket adds 0.2" (6 mm) to depth

Motion sensor: Passive infrared sensor

Battery pack capacity:

954mAh nominal capacity

Charging requirement: 5V/1.5A charger

Charging time: Up to 7 hours

Speaker: 1W, 8Ω speaker

Microphone: Single, omni-directional, analog, >-40dBV/Pa

Included accessories

- Charging cable
- Mounting plate
- Mounting screws and anchors
- Installation guide
- 10° tilt wedge

www.alarm.com











© 2023 Alarm.com. All rights reserved. 230209

LED guide

- 1 Top LED
- 2 Button LED



Charging States			
Mode	Description	Top LED Behavior	Button LED Behavior
Charging	The battery pack is plugged in and charging.	Solid orange 	On Button Press Solid green = >75% charged  Solid yellow = 75% - 20% charged  Alternating red and blue = < 20% charged 
Fully charged	The battery pack is fully charged.	Solid green 	On Button Press Solid green 
Failure charging	The battery pack stopped charging because the device was plugged in too long. Remove the charging cable and re-attempt charging after an hour. If you see the same behavior, please contact your provider.	Alternating orange and green 	Alternating red and white 
Operational temperature range for charging exceeded	The battery pack's internal temperature is either too hot or too cold. Please charge the battery pack in a room temperature environment.	Solid green or solid orange  	Alternating red and yellow  Or Alternating red and white 

Operational States		
Mode	Description	Button LED Behavior
Standby or off	The camera is in standby mode (normal operation) or the battery is drained and requires recharging.	Off 
Local connection	The camera has a local network connection.	Solid green 
No local connection	The camera does not have a local network connection.	Solid red 
Low battery	The camera's battery is low and requires a recharge.	Alternating red and blue 
Connecting to network	The camera is powered on and connecting to a network.	Blinking red 
WPS mode	The camera is in WPS pairing mode. To enter this mode, press and hold the button for 30-45 seconds.	Blinking blue 
AP mode	The camera is in AP pairing mode. To enter this mode, press and hold the button for 46-60 seconds.	Blinking white 
Power cycle	The camera is being power cycled. To enter this mode, press and hold the button for 61-75 seconds.	Blinking yellow 
Factory reset	The camera resetting to factory default. To enter this mode, press and hold the button for 76-180 seconds.	Alternating red and green 
Firmware upgrade	The camera's firmware is being updated.	Blinking yellow rapidly 



Alarm.com Smart Chime Data Sheet

ADC-W115C

www.alarm.com

© 2021 Alarm.com. All rights reserved. 210107

Specifications

Wi-Fi Connection: 802.11 b/g/n, 2.4 GHz

Wi-Fi Security: WPA2

LED Indicators: 4

Buttons: WPS, Reset

Antennas: 2 Wi-Fi

Chime: 1.5 W speaker, 77 dB

Operating Temperature: 32°F to 104°F
(0°C to 40°C)

Operating Humidity: 10% to 90%
(non-condensing) RH

Dimensions (H x W x D): With antennas 5.0 x
1.0 x 2.1" (12.7 x 13.0 x 5.4 cm)

Without antennas 3.3 x 3.3 x 2.1" (8.5 x 8.5 x
5.4 cm)



Overview

Designed to work seamlessly with the Alarm.com platform, the ADC-W115C serves as a robust Wi-Fi extender and customizable wireless doorbell chime. Add the Alarm.com Smart Chime to an account when an in-home chime is not a feasible option during a doorbell camera installation. Simply plug the ADC-W115C into a wall outlet, pair with the existing router, add a doorbell camera, and enjoy boosted network signals that provide instantaneous chime notifications.

Features

- Wireless doorbell chime
- Wi-Fi extender (2.4 GHz)
- Adjustable chime volume
- Customizable tones
- Simple, plug-in installation
- Remote management and troubleshooting

In the Box

- ADC-W115C Alarm.com Smart Chime
- Installation Guide

LED Guide

🔌	☁️	🔗	🔄	🔌☁️🔗🔄
On Device powered on	On Connected to Internet	On Device connected to chime	Off WPS mode not enabled	Blinking (escalating) Firmware upgrade in progress
Off Device powered off	Off No local or Internet connection	Off No device connected to chime	Blinking (slowly) WPS mode enabled to connect to router	Blinking (simultaneously) Reset in progress
Blinking Device booting up	Blinking Local connection, no Internet connection	Blinking (3 quick blinks) New device connected to chime	Blinking (rapidly) WPS mode enabled to connect to device	
	Blinking (5 quick blinks) Communication test initiated			