PARADOX™

Digiplex EVO

High Security and Access System



Description

Digiplex EVO systems (EVO192) provide the highest level of protection for banks, government sites, luxurious residential homes and any place where maximum security is essential. The modular concept of these systems provide installers with labour-saving features that make expanding, installing and servicing these systems quick and convenient.

Expand your system by adding expansion modules anywhere, in any combination, on the 4-wire combus. Modules are connected to the combus at the most convenient location and their zone inputs are assigned to the desired zone and partition. Keyswitches, remote controls, and unused module inputs do not use zones. Once installed, all combus modules (including motion detectors) can be programmed remotely via a keypad, or the BabyWare PC software.

Digiplex EVO integrates access control solutions. Your alarm system user database can be used to manage the access for up to 32 doors, and the monitoring of these doors can be included in any partition. By merging security and access control, Digiplex EVO systems increase the level of protection offered by security systems to a whole new level.

Feature Comparison

Feature	EVO192
Maximum Zones*	192
On-board Zones	8 (16 with ATZ)
Partitions	8
User Codes	999
Multibus	✓
Stay Arming	✓
Panel In-field Firmware Upgradable	✓
Access Control (Doors)	32
Access Levels / Schedules	16 / 32
Events Buffered	3584
PGMs	32 (5 on-board)
PGM +/- Trigger	✓
Virtual Zones**	32
Expansion Modules*	254
Supports IP / GPRS / GSM Communication (PCS Series)	✓
Supports VDMP3 Plug-in Voice Module	✓
Supports IP150 Internet Module	✓
Software	NEware, BabyWare
Listen-in Capabilities	✓

* Can be any combination of hardwire, wireless or addressable zones, or modules
** Automate PGM activations without occupying security zones

PARADOX KEEPING MY FAMILY SAFE

paradox.com

System Overview

Control Panels

EVO192

EVOHD

4-wire EVO BUS

Keypads

TM70

TM70:	Intuitive Touchscreen
TM50:	Intuitive Touchscreen
K656:	Touch Sense Keypad
K641+:	32-Character Blue LCD Keypad
K641LX:	32-Character Blue LCD Keypad with Built-in Transceiver
K641R:	32-Character Blue LCD Keypad with Integrated Card Reader

Video Monitoring

HD88

HD88:	Outdoor 720p HD Camera
HD78F:	Event-Driven Indoor Security IP Camera / Detector

Digital Bus Detectors

NV75MX

NV75MX:	16M Dual Mironel Optics Pet Immune Anti-Mask Detector
NV780MX:	Dual Side-View Outdoor Detector with Anti-Mask and Pet Immunity
NV35MX:	Wired Outdoor / Indoor Window and Sliding Door Dual Detector
NVX80:	High-End Motion Detector with Anti-Mask and SeeTrue™ Technology for Indoor / Outdoor Use
DM50:	Dual Element Motion Detector
DM60:	Quad Element Motion Detector
DM70:	Dual-Optic High-Performance PIR
DG85:	Outdoor Dual-Optic High-Performance PIR
DG457:	GlassBreak Detector
DG467:	360° Ceiling-Mounted PIR

Communicator Modules

PCS265LTE

PCS265LTE:	LTE / 4G / 3G / 2G / GSM Communicator Module
PCS250 / G:	GPRS / GSM Communicator Module
IP150:	IP Communicator
VDMP3:	Plug-In Voice Module

Zone Expansion & Door Contact Modules

ZX82

ZC1:	Door Contact Module
ZX1:	1-Zone Expansion Module
ZX82:	8-Zone Expansion Module
ZX8:	8-Zone Expansion Module
RTX3:	2-Way Wireless Expansion Module

Software & Accessories

Insite GOLD

Insite GOLD:	Mobile App
PMC5:	Memory Key
307USB:	Direct Connect Interface
BabyWare:	PC Software
NEware:	End-User Management Software
InField:	Firmware Upgrade Software

Access Control Modules



ACM12 R915

ACM12:	4-Wire Access Control Module
R910*:	4-Wire Proximity Card Reader
R915*:	4-Wire Proximity Card Reader / Keypad

*Various cards available

Special Modules & Accessories

PGM82

PGM82:	8-PGM Expansion Module
PGM4:	4-Output Expansion Module
PS25:	2.8A Supervised Power Supply
PS45:	5A Supervised Bus Power Supply
HUB2:	2-Port Hub
PRT3:	Integration Module

For compatibility details, visit us at paradox.com

Feature Details

Internet Communication (IP150)

The IP150 Internet Module allows you to control and monitor your security system remotely through any web browser. It allows for email notifications of important system events such as alarms, arm/disarm events, and troubles. For example, receive an email at work when your kids get back from school. You can also view the live status of your system and arm/disarm it. For example, you have just left your office for the weekend but are not sure you remembered to arm the system. Simply check the status of your system from a laptop and arm it.

Wireless Communication (PCS Series)

The PCS series modules provide the Digiplex EVO control panels with wireless communication capabilities to report system events via IP, GPRS, and/or GSM. Whether it be uploading/downloading via IP or GPRS, receiving system status and events by voice or text message, or reporting to the monitoring station via IP, GPRS, or GSM, the PCS series enhances the communication capabilities of any Digiplex EVO installation.

Voice Communication (VDMP3)

The VDMP3 is a plug-in, voice-assisted module that can be programmed to call up to 5 telephone numbers in the event of an alarm. For example, when an alarm occurs at your store during off-hours, every employee can receive notification via telephone; e.g., "Area 1 in alarm. Zone 3. Press 1 to disarm the system..." You can also call the VDMP3 from an outside line, enabling you to arm or disarm the system as well as activate PGMs. The VDMP3 essentially turns any outside telephone into a keypad. The VDMP3 is easy to install; plug it in directly onto the panel, set the phone numbers, and select the activation event.

In-field Upgradable

Digiplex EVO is not only easy to install, but is also fully in-field upgradable for simple on-site updates. The process is effortless; connect the PC to the panel and you are a few clicks away from performing a complete system upgrade within minutes. No need to change panels or hardware; all the updates are done using Paradox's InField Firmware Upgrade Software.

Access Control

Access control can be added to the Digiplex EVO system to provide additional control over who has access to your premises, even when your security system is not armed and you are not there to supervise. With added access control you can limit access to certain areas, disallow access to others, or control entire groups of people according to their schedule or privileges. Make your premises inadmissible to all except those with access cards, track anybody who enters your premises, print detailed reports of access control activities, and more.

App-based System Control

The Insite GOLD app enables you to remotely access your Paradox security system and view your system cameras. Insite GOLD provides lots of functionality and information at one's fingertip. It has an intuitive user-interface which enables you to easily connect to your security system and edit its settings. Now you can control your Paradox security system from any Android / iOS smartphone.

TM70 Overview

TM70: Intuitive Touchscreen

SpotOn Locator™

Upload photos, images, or schematics to eliminate the need for deciphering LED zone lights. These images display any door, window, or motion detector that are active. Since the images are uploaded by the user, they are truly customized, and can be unique to each installation. SpotOn Locator™ is integrated in the original firmware, and when purchased, is unlocked with an authorization code.

OneScreen Monitoring™

Provides a real-time visual display of the system's status on one screen. It allows the user to choose which partitions will be displayed showing arming level, alarm, ready, and troubles. It also displays zone statuses; open, close, bypass, alarm, and tamper. OneScreen Monitoring™ also features Solo Test™ mode, which allows installers and users to easily test all system zone's via the TM70 Touch's screen. OneScreen Monitoring™ is integrated in the original firmware, and when purchased, is unlocked with an authorization code.

Specifications

Display	16-bit, color LCD; 8.6 x 15.4 cm (3.1 x 5.9 in.), 800 x 480 pixels
Input Voltage	9 to 15 Vdc
Current Consumption	250 mA at max brightness + 80 mA sounder
Keypad Zone Input	1 for a detector or external temperature sensor
Tamper	Built-in, cover and wall
Humidity	5 to 90%
Operating Temperature	-10 to 55 °C (14 to 131 °F)
Compatibility	Swan, EVO, Spectra, Magellan

Note: All control panel outputs are rated to operate between 11.4 Vdc and 12.5 Vdc.

TEVO-G2K rev.13 - Printed in Canada 02/2019

Specifications PRX2780000033-P2C

The PRX2780000033-P2C is a metal box enclosure for provision multiple module and panel mounting.

Features:

- Many punch-out holes for simple wiring
- Easy door removal
- Sizes: 28cm X 28cm X 7.6cm (11" x11" x 3")

Specifications PRXK-TK278

The PRXK-TK278 is a BOM Kit for 1x tamper switch PRX2502302000-P2C and 1x tamper bracket PRX2781030000-P2C to suit with Paradox Metal Box Enclosure PRX2780000033-P2C; to protects against tampering (opening door or removal from wall).

DIGIPLEX EVO

EVO48
EVO192

User Guide



PARADOX KEEPING MY FAMILY SAFE

PARADOX™

Compatibility

The K641+ is compatible with EVO192 and EVOHD. Please refer to the *Technical Specifications* section for more details.

Technical Specifications

Operating Voltage	9 to 16Vdc
Operating Temp.	-10 to 55°C (14 to 131°F)
Power Consumption	Maximum current - 150mA
Dimensions	15 x 12.6 x 2.7 cm (6 x 4.9 x 1.06 in.)
Weight	230g (8.1 oz)
Humidity	5-93%
Compatibility	EVO192 v2.16 or higher and EVOHD V1.0 or higher
Compliance	EN50131-3 Grade 3; Environmental Class II Certification Body: Applica Test and Certification

Warranty

Warranty: For complete warranty information on this product, please refer to the Limited Warranty Statement found on paradox.com. Your use of the Paradox product signifies your acceptance of all warranty terms and conditions.

N24563
Z109

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Printed in Canada | 04/2019

K641+ Keypad Quick Install Guide

K641+-EI03

The K641+ keypad allows you to configure your Paradox system through its interface.

Installation

1. Using a flathead screwdriver, pry the front housing assembly from the backplate.



Figure 1: Opening the K641+

KEEPING MY FAMILY SAFE

2. If using surface mounted cabling, you will need to knock out the plastic tab (#1) at the top or bottom of the K641+ backplate in order to for the cable to pass through, refer to Figure 3.
3. Insert needle nose pliers into the appropriate plastic tab and carefully break off.



Figure 2: Surface-mount cabling plastic tab removal

4. Mount the backplate to the wall by securing a M3.5 #6 screw in each of the dedicated mounting holes and tamper hole while ensuring that the top is up, as shown in Figure 3. For EN installations, use the designated mounting holes (#3).



Figure 3: K641+ Backplate

5. Connect the 4-wire combus wires to the connector bus, as shown.



Note:
ZX1 is a Programmable input
PGM is a Programmable output

Figure 4: Wiring

6. Assemble both items by joining the hooks on the backplate to their respected slots on the front housing assembly.
7. Secure the front housing to the backplate by snapping it into place.
   The installation process is now complete.

Configuration

Modules can be configured using this keypad or BabyWare. The preferred option is to use BabyWare to configure the system.

All Disarmed 2014/19/05 16:00	User Access Code [*_]	Installers Code [_]

To configure modules through the keypad

1. Press and hold the 0 (number zero) key.
   NOTE: *The area must be disarmed to configure modules.*
2. Initially you will see **User Access Code** but within 2 seconds it will change to **Installer Code.**
3. When the Installer code appears, input the Installer code number, the default number is **[000000]**.
4. Input the 4 digit section code for Module Programming **[4003]**.
   NOTE: *You need module serial numbers for programming.*
5. Input the module serial number.
6. Input module section **[001]**.
7. Now you can start module programming.

Quick Start

K641+ Keypad



How To Arm

Arming When Exiting (Regular/Force Arm)

To arm your system when exiting:

Step	Description
1.	Enter your [ACCESS CODE]. • To Regular arm, press the [ARM] key (arms entire area when all zones are closed). • To Force arm, press the [FORCE] key (arms entire area without waiting for all zones to close).
2.	Select the desired area or press the [0] key for all areas.

Arming When Staying (Stay/Instant Arm)

To arm your system when staying:

Step	Description
1.	Enter your [ACCESS CODE]. • To Stay arm, press the [STAY] key (arms area's perimeter only, which allows you to remain in the protected area). • To Instant arm, press the [5] key (stay arms the area but an alarm will occur instantly if any zone opens).
2.	Select the desired area or press the [0] key for all areas.

K641+-EQ00
Printed in Canada - 02/2014

How to Disarm

To disarm your system when entering:

Step	Description
1.	Enter your [ACCESS CODE].
2.	Select the desired partition if necessary.

To disarm from within the perimeter:

Step	Description
1.	Enter your [ACCESS CODE].
2.	Press the [DISARM] key.
3.	Select the desired partition if necessary.

Panic Keys

To send a silent or audible alarm to your security company, press and hold one of the key combinations listed below, for two seconds.

Panic Alarm	Key Combinations
Police	Keys [1] & [3]
Medical	Keys [4] & [6]
Fire	Keys [7] & [9]

Alarm Memory Display

To view the alarms that occurred during the last armed period:

Step	Description
1.	Disarm the system.
2.	Press [MEM]. All zones that were breached during the last armed period will be displayed. Use the arrow keys to view the zones.
3.	Press [CLEAR] to save and exit.

Trouble Display

The LCD screen will display all troubles when they occur. To view and clear troubles:

Step	Description
1.	Press [TBL].
2.	Scroll through the list of troubles using the arrow keys. Refer to the EVO User Guide for trouble descriptions and instructions.
3.	Perform the recommended repair instructions to clear the trouble. If no instructions are given, contact your security company.
4.	Press [CLEAR] to exit.

How to Bypass Zones

When a zone is bypassed, it remains unarmed when the corresponding area is armed. To bypass zones:

Step	Description
1.	Enter your [ACCESS CODE].
2.	Press [BYP].
3.	Select the zone you want to bypass by entering the zone number, e.g., zone 3=003.
4.	Press [Enter].

Specifications DFMWP16

The DFMWP16 is combo siren and strobe (slim design).

- New design
- Siren tone selectable for different applications
- Sound volume adjustable: low dB for testing and high dB for normal operation
- Bright: new LED strobe design
- Independent siren and strobe operation
- High quality UV treated case
- Weatherproof
- Front and back tampers
- EOLRs built in, suitable for most major alarm panels

Operating voltage: 9-15VDC

SPL @ 1meter: 110dB

Siren current draw: 150mA

Strobe current draw: 50mA

Siren tone selectable: Tone 1: warble; Tone 2: Hi/Lo

Dimension: 200 x 110 x 40mm


SECOR
WP16 Combo Siren/Strobe
Voltage: 9-15VDC
Current: Max 150mA @ 12VDC
High Volume: 110±3 dB @ 1meter
Low Volume: 95±3 dB @ 1meter
Tone 1: Warble
Tone 2: Hi/Lo
J1
Volume High
Low
Siren Tone 1
Tone 2
J2
Tamper output EOL
6.8K
5.6K
3.3K
2.2K
0
J3
+ Siren – Input
+ Strobe – Input
+ LED – Night Comfort
Tamper Output
Spare

SECOR

Specifications DFMWP08

The DFMWP08 is indoor top hat piezo.

Input voltage: 12VDC

SPL @ 1meter: 105dB

Current draw: 90mA

VRLA 12V7AH

SA12V7

Specifications

Nominal Voltage	12 V
Nominal Capacity 20HR	7.0 AH
Dimensions	Length 151±1mm (5.94 inches) Width 65±1mm (2.56 inches) Container Height 95±1mm (3.74 inches) Total Height (with terminal) 100±1mm (3.94 inches)
Approx Weight	Approx 2.10 kg (4.63 lbs)
Terminal	F1
Container Material	ABS Plastic
Lead Material	Purity Lead 99.995%
Sulfurid Acid	Distilled Sulfurid Acid (Zero metal content)
Separator	AGM
Rated Capacity	7.00 AH/0.350A (20hr, 1.80V/cell, 25°C/77°F) 6.53 AH/0.653A (10hr, 1.80V/cell, 25°C/77°F) 6.00 AH/1.20A (5hr, 1.75V/cell, 25°C/77°F) 5.37 AH/1.79A (3hr, 1.75V/cell, 25°C/77°F) 4.55 AH/4.55A (1hr, 1.60V/cell, 25°C/77°F)
Max. Discharge Current	105A (5s)
Internal Resistance	Approx 23mΩ
Operating Temp.Range	Discharge : -15 - 50°C (5 - 122°F) Charge : 0 - 40°C (32 - 104°F) Storage : -15 - 40°C (5 - 104°F)
Nominal Operating Temp.Range	25±3°C (77±5°F)
Cycle Use	Initial Charging Current less than 2.1A. Voltage 14.4V - 14.7V at 25°C (77°F) Temp.Coefficient -30mV/°C
Standby Use	No limit on Initial Charging Current Voltage 13.5V - 13.8V at 25°C (77°F) Temp.Coefficient -20 mV/°C
Capacity affected by Temperature	40°C (104°F) 103% 25°C (77°F) 100% 0°C (32°F) 86%
Self Discharge	Sentry AGM series batteries may be stored for up to 6 months at 25°C (77°F) and then a freshening charge is required. For higher temperatures the time interval will be shorter.

Applications

- All purpose
- Standby Applications
- Recreation Vehicles
- Uninterruptible Power Supply (UPS)
- Electric Power System (EPS)
- Fire & Security
- Generators
- Medical Equipment

Dimensions

F1 Terminal

Unit: mm (inches)



Constant Current Discharge (Amperes) at 25°C (77°F)

F.V/Time	5min	10min	15min	20min	30min	45min	1h	2h	3h	4h	5h	6h	8h	10h	20h
1.85V/cell	18.0	12.8	10.48	8.79	6.53	4.79	3.86	2.29	1.69	1.36	1.14	0.98	0.774	0.640	0.345
1.80V/cell	21.4	14.3	11.4	9.44	6.94	5.05	4.03	2.38	1.74	1.40	1.17	1.01	0.791	0.653	0.350
1.75V/cell	24.2	15.6	12.2	10.0	7.29	5.27	4.18	2.45	1.79	1.43	1.20	1.03	0.805	0.663	0.357
1.70V/cell	26.7	16.7	12.9	10.5	7.59	5.46	4.32	2.51	1.83	1.46	1.22	1.05	0.817	0.672	0.361
1.65V/cell	28.8	17.7	13.5	10.9	7.86	5.62	4.46	2.57	1.86	1.48	1.23	1.06	0.826	0.680	0.365
1.60V/cell	30.6	18.6	14.1	11.3	8.09	5.76	4.55	2.61	1.89	1.50	1.25	1.07	0.834	0.685	0.367

Constant Power Discharge (Watts/Cell) at 25°C (77°F)

F.V/Time	5min	10min	15min	20min	30min	45min	1h	2h	3h	4h	5h	6h	8h	10h	20h
1.85V/cell	34.2	24.5	20.2	17.1	12.8	9.44	7.64	4.56	3.37	2.72	2.29	1.99	1.565	1.296	0.701
1.80V/cell	40.2	27.2	21.9	18.3	13.5	9.91	7.96	4.72	3.47	2.79	2.34	2.03	1.593	1.318	0.708
1.75V/cell	45.1	29.5	23.3	19.3	14.2	10.3	8.23	4.85	3.55	2.85	2.39	2.06	1.616	1.344	0.719
1.70V/cell	49.2	31.3	24.5	20.1	14.7	10.6	8.48	4.96	3.62	2.89	2.42	2.09	1.633	1.347	0.725
1.65V/cell	52.6	32.9	25.5	20.8	15.2	10.9	8.73	5.05	3.68	2.93	2.45	2.11	1.649	1.359	0.731
1.60V/cell	55.5	34.3	26.3	21.5	15.5	11.2	8.88	5.12	3.72	2.96	2.47	2.13	1.660	1.367	0.734

Discharge Characteristics



Float Charging Characteristics



Temperature Effects in Relation to Battery Capacity



Effect of Temperature on Long Term Float Life



Cycle Life in Relation to Depth of Discharge



Self Discharge Characteristics



No supplementary charge required
(Carry out supplementary charge before use if 100% capacity is required

Supplementary charge required before use. Optional charging way as follows the table charging system.

Supplementary charge may often fail to recover the capacity. The battery should never be left standing still this is reached.

Charging System

D O D	Currency Limit (A)	Constant Voltage (V)	Fully Charged Time (h)
20	0.15C_{10}	13.5-13.8 vpc (12V) 6.75-6.9 vpc (6V)	10
	0.20C_{10}		8
50	0.15C_{10}	13.5-13.8 vpc (12V) 6.75-6.9 vpc (6V)	15
	0.20C_{10}		12
80	0.15C_{10}	13.5-13.8 vpc (12V) 6.75-6.9 vpc (6V)	16
	0.20C_{10}		14
100	0.15C_{10}	13.5-13.8 vpc (12V) 6.75-6.9 vpc (6V)	20
	0.20C_{10}		18

State of Charge (SOC)

Open Circuit Voltage (V/cell)	Open Circuit Voltage (12V/cell)	Open Circuit Voltage (6V/cell)	State of Charge (% of full charge capacity)
2.14-2.15	12.84-12.90	6.42-6.46	100
2.12-2.13	12.72-12.78	6.36-6.39	90
2.11	12.66	6.33	80
2.09	12.54	6.27	70
2.07	12.42	6.21	60
2.05	12.30	6.15	50

SPB
Sealed Performance Batteries

Domestic Sales | Ph: +61 (0)7 3386 1102 | Fax: +61 (0)7 3102 9913
sales@spb.net.au | **www.sealedperformance.com.au**
National Warehouse | 1 Ant Road | Yatala, Brisbane QLD 4207
Melbourne Office | 2/9 Compark Circuit | Mulgrave, Melburne VIC 3170

	REVISED	DRAWN	APPROVED
①	AMENDED PACKING QTY AND CARTON SIZE	JACKY 10/08/09	GARY 10/08/09
②	ADDED DATE CODE ON CASE AND DIMENSIONS	JACKY 07/12/09	GARY 07/12/09
③	ADDED PASSED LABEL ON CARTON	TODD 22/12/10	JACKY 22/12/10
④	AMENDED AC PINS DIMENSION & ADDED WIRES COLORS	ANLEI 01/11/12	ANLEI 01/11/12
⑤	CHANGED CROSS-SHAPPED SCREW TO SHAPE ⌶ SCREW ON CASE	MARK 31/08/15	FREDERICK 31/08/15





NOTES:
1. OUTPUT CORD:20AWGX3C 1.83M Lead Free GREY (RAL7035)
2. CASE: GREY (RAL7035)
3. SECURITY SCREW IS AN ESSENTIAL REQUIREMENT, BOTH "⌶" AND "△" SHAPE ARE ACCEPTABLE



LABEL ARTWORK
Black word on Silver base label

TE DRAWING NO: TE40-0001 R5						PART NO: 16VAC1500MPS/6		
DESCRIPTION: AC ADAPTOR EI-48Q,16VAC1500mA, 3 WIRE - MEPS								
SIZE	A4	DATE	30/04/09	CHECKED	KEVIN 30/04/09	KG ORDER REF: 0420	SHEET 1 OF 3	*TOLERANCES UNLESS OTHERWISE STATED*
UNIT	MM	DRAWN	KEVIN	APPROVED	FRANK 30/04/09	CUSTOMER: TE		*X.= +/-1*
SCALE	NTS	MANU:				DATE:		*.X=+/-0.5*
								.XX=+/-0.2

ITEM		SPECIFICATION
1. Primary rated input voltage		AC240V 50Hz 133mA
2. Secondary rated output voltage and current		Unloaded voltage: AC 18 V ± 5% Loaded Voltage : AC 16 V ± 5% AT 1500 mA
3. Ripple voltage		*** mV (RMS) MAX. AT Rated Loading
4. Insulation resistance		Primary - secondary: DC 500 V 100 MΩ Min
5. Dielectric withstand test		Primary - secondary: AC 3.64 KV 1 seconds
6. Temperature rise		At rated loading 90℃ max. For input coil (By resistance method) and 55℃ max. on case surface (By use of thermometer)
7. EFFICIENCY		≥ 79%
8. Leadout	Primary	SAA PLUG IN TYPE
	Secondary	PVC cable length: 1.8 Meter Colour : GREY (RAL7035) Wire size: AWG#20/3C Plug : STRIPPED AND TINNED
9. Test circuit		
10. Case		SAA48 colour = GREY (RAL7035)

	REVISED	DRAWN	APPROVED
1	AMENDED PACKING QTY AND CARTON SIZE	JACKY 10/08/09	GARY 10/08/09
2	ADDED DATE CODE ON CASE AND DIMENSIONS	JACKY 07/12/09	GARY 07/12/09
3	ADDED PASSED LABEL ON CARTON	TODD 22/12/10	JACKY 22/12/10
4	AMENDED AC PINS DIMENSION & ADDED WIRES COLORS	ANLEI 01/11/12	ANLEI 01/11/12
5	CHANGED CROSS-SHAPPED SCREW TO SHAPE ⌶ SCREW ON CASE	MARK 31/08/15	FREDERICK 31/08/15

TE DRAWING NO: TE40-0001 R5 | PART NO: 16VAC1500MPS/6

DESCRIPTION: AC ADAPTOR EI-48Q,16VAC1500mA, 3 WIRE - MEPS

SIZE	A4	DATE	30/04/09	CHECKED	KEVIN 30/04/09	KG	ORDER REF: 0420	SHEET 2 OF 3
UNIT	MM	DRAWN	KEVIN	APPROVED	FRANK 30/04/09	CUSTOMER: TE		
SCALE	NTS	MANU:				DATE:		

TOLERANCES UNLESS OTHERWISE STATED
X.= +/-1
.X=+/-0.5
.XX=+/-0.2

	REVISED	DRAWN	APPROVED
1	AMENDED PACKING QTY AND CARTON SIZE	JACKY 10/08/09	GARY 10/08/09
2	ADDED DATE CODE ON CASE AND DIMENSIONS	JACKY 07/12/09	GARY 07/12/09
3	ADDED PASSED LABEL ON CARTON	TODD 22/12/10	JACKY 22/12/10
4	AMENDED AC PINS DIMENSION & ADDED WIRES COLORS	ANLEI 01/11/12	ANLEI 01/11/12
5	CHANGED CROSS-SHAPPED SCREW TO SHAPE ⌶ SCREW ON CASE	MARK 31/08/15	FREDERICK 31/08/15



1 PC/WHITE BOX



BLACK PRINTING



20 BOXES/CARTON ①



SHIPPING CARTON
PLEASE FOLLOW ORDER TO PRINT SHIPPING MARKS.

RoHS COMPLIANT
PASSED
QC Report No.:
Checked by :
Inspect date :

③

ONLY ONE RoHS+PASSED LABEL ON CARTON
RoHS LABEL(55X25MM)
GREEN GROUNDING YELLOW TEXT
PASSED LABEL(55X36MM)
BLUE GROUNDING WHITE TEXT
WHITE GROUNDING BLUE TEXT

ADHESIVE TAPE



①

TE DRAWING NO: TE40-0001 R5

PART NO: 16VAC1500MPS/6

DESCRIPTION: AC ADAPTOR EI-48Q,16VAC1500mA, 3 WIRE - MEPS

SIZE	A4	DATE	30/04/09	CHECKED	KEVIN 30/04/09	KG	ORDER REF: 0420	SHEET 3 OF 3
UNIT	MM	DRAWN	KEVIN	APPROVED	FRANK 30/04/09	CUSTOMER: TE		
SCALE	NTS	MANU:				DATE:		

TOLERANCES UNLESS OTHERWISE STATED
X.= +/-1
.X=+/-0.5
.XX=+/-0.2

Specifications TELLC0280

The TELLC0280 is the telephone lead with 606 Socket and 2 Meter length of Telephone Cord.

Colour: Ivory.